






LE1458_SHB340XX

		Spare part number	
1	Glass lid		<i>Refer to page 3</i>
2	Lid hinge (x2)	SSPA0010	
2A	Lid Shut-off switch (x1)	SSPA0611	
3	Pan support		<i>Refer to page 3</i>
4	Pan support mounts		
	<i>Plastic clips, for chrome pan rest only</i>	SSPA0041	Set of 4 clips, with screws
	<i>Rubber bushes, for cast pan rest only</i>	SSPA0800	Set of 6 bushes
5	Burner assembly		
	<i>Production date: < 23/09/12 (E266N...)</i>	SSPA0114	
	<i>Production date: ≥ 24/09/12 (E267N...)</i>	SSPA0812	
6	Control knobs		<i>Refer to page 4</i>
7	Ignition switches and wire harness	SSPA0335	
8	Gas tap (x2)		
	<i>Production date: < 23/09/12 (E266N...)</i>	SSPA0416	
	<i>Production date: ≥ 24/09/12 (E267N...)</i>	SSPA0425	
9	Bezel	SSPA0817	
10	Thermocouple		
	<i>Production date: < 23/09/12 (E266N...)</i>	SSPA0676	
	<i>Production date: ≥ 24/09/12 (E267N...)</i>	SSPA0681	
11	Electrodes (x4, 900mm)		
	<i>Production date: < 23/09/12 (E266N...)</i>	SSPA0310	
	<i>Production date: ≥ 24/09/12 (E267N...)</i>	SSPA0320	
12	Spark generator	SSPA0300	
13	Worktop fixing kit	SSPA0025	
14	Lid bump stops (x2)	SSPA0040	



xxxxxx = not available anymore

Glass lid

Spare part number	Glass	
SSPA0224	Chequer	
SSPA0225	Striped	
SSPA0226	Smoked black Clear	
SSPA0227	Solid black	
N/A	Oyster	




xxxxxx = no longer available

Pan support



Description	Chrome (including mounts)	Cast iron (including mounts)
Spare part number	SSPA0956	SSPA0968

Control knobs

Control Knob			
Spare part number	SSPA0911	SSPA0918	SSPA1201
Colours available	Black (.BK)	Black (.BK)	Matt Nickel (.MNK)
Set quantity	3	3	3

xxxxxx = not available anymore