



LE1262\_SOV420X

|    |                        | Spare part number | Spare part number | Colours available |
|----|------------------------|-------------------|-------------------|-------------------|
| 1  | Oven burner            |                   |                   |                   |
| 2  | Electrode              |                   | SSPA0190          |                   |
| 3  | Thermocouple           | SSPA0158          |                   |                   |
| 4  | Spark generator        | SSPA0302          |                   |                   |
| 5  | Ignition switch        | SSPA0380          |                   |                   |
| 6  | Light switch*          | SSPA0590          |                   |                   |
| 7  | Oven tap               | SSPA0451          |                   |                   |
| 8  | Oven knob              | SSPA0910          |                   | .CR/BK            |
| 9  | Door catch             |                   |                   |                   |
| 10 | Door handle            | SSPA0058          |                   |                   |
| 11 | Oven door              | SMAO5445          |                   | .BKLX             |
| 12 | Door hinge brackets 2x |                   | SSPA0057          |                   |
| 13 | Hinge pin 2x/spring    | SSPA0059          |                   |                   |
| 14 | Glass inner door       | SSPA0252          |                   |                   |
| 15 | Oven seal              | SSPA0061          |                   |                   |
| 16 | Oven shelf             | SSPA0981          |                   |                   |
| 17 | Oven lamp*             | SSPA0560          |                   |                   |

\* Only applicable for SOV4205

~~XXXXXX~~ = not available anymore