


LE766_C502C-X_1114-V03

		Spare part number	Spare part number	Spare part number	Colours available
1	Cover		90713		62, 127
2	Seat				
3	Bowl		90727		62, 127
4	Screw				
5	Sticker control knob		90725	90724	62, 127
6	Control PCB		<i>C-model</i>	<i>X-model</i>	
7	Control knob		<i>(before 90701)</i>	<i>(before 90709)</i>	
8	Cosmetic cover straight Cosmetic cover curved				
9	Water level sensor (<i>X-model only</i>)	90702			
10	Bench welded				
11	Cap waterfill funnel	16848			16
12	Waterfill funnel		90710	90719	
13	O-ring		<i>waterfill funnel</i>	<i>waterfill funnel</i>	
14	Waterfill elbow		<i>275mm</i>	<i>310mm</i>	
15	O-ring				
16	Tube PVC				
17	Drain connector				
18	Sight tube				
19	Clip sight tube	90711			
20	Drain tube		90703		
21	Tunnel				
22	Screw				
23	Base				
24	Pocket cover				
25	Housing PCB				
26	Main PCB	90704	90712		
		<i>C-model</i>	<i>X-model</i>		
27	Retaining plate				
28	Magnet				
29	Magnet basket				
30	Flange lock				
31	Bushing				
32	Saddle				
33	Spring		51802		
34	Bracket				
35	Shaft				
36	Link				
37	Drain plug				
38	O-ring				
39	Blind plug water fill				
40	Pump	90714			
41	Water supply tube				
42	Nozzle		90705		127
43	O-ring				
44	Wiring harness	90720	90721		
		<i>C-model</i>	<i>X-model</i>		
45	Bayonet	90726			62


~~xxxxx~~ = not available anymore



LE757_C503L_0518-V03

		Spare part number	Spare part number	Colours available
1	Cover		90713	62, 127
2	Seat			
3	Bowl		90727	62, 127
4	Screw			
5	Sticker control knob		90723	62, 127
6	Control PCB		(before 90715)	
7	Control knob			
8	Cosmetic cover straight Cosmetic cover curved			
9	Bench welded			
10	Base			
11	Tunnel			
12	Screw			
13	Pocket cover			
14	Housing PCB			
15	Main PCB	90716		
16	Retaining plate			
17	Magnet			
18	Magnet basket			
19	Flange lock			
20	Screw			
21	Bushing			
22	Saddle			
23	Spring		51802	
24	Bracket			
25	Shaft			
26	Link			
27	Wiring harness	90722		
28	Water supply tube			
29	Hose clamp			
30	Solenoid valve		90717	
31	Hose nut			
32	Hose barb			
33	O-ring			
34	Nozzle		90718	
35	Water supply tube			
36	Water supply tube			
37	Bracket			
38	Screw			
39	Vacuum breaker	16833		
40	Screw			

XXXXX = not available anymore



LE758_C500-WHT_1114-V02

		Spare part number	Spare part number	Spare part number	Colours available		
1	Sliding cover	32301			06		
2	Blade opener	32300	32331 <i>mechanism right</i>	32332 <i>mechanism left</i>	16		
3	Washer						
4	Seal parker						
5	Mechanism retainer						
6	Holding tank plate Left hand version						
6A	Holding tank plate Right hand version	32328					06
7	Seal mechanism	50724					06
8	Lip seal	23721					
9	Seal plate						
10	Screw						
11	Blade	50731					
12	Bearing						
13	Blade arm						
14	Bushing						
15	Screw						
16	Blade driver						
17	Support track						
18	Screw						
19	Retainer	90706					
20	Magnet						
21	Float arm						
22	Upper automatic vent	23722			06		
23	Seal						
24	Foam						
25	Pour out spout		32306		06		
26	Measuring cup	25810			16		
27	O-ring						
28	Pull handle		51805		16		
29	Pull handle bushing right						
30	Pull handle bushing left						
31	Spring						
32	Waste-holding tank complete		90707 <i>right hand version</i>	90708 <i>left hand version</i>	06		
33	Tank lock clip	51801			16		
34	Wheel		32308		06		
35	Wheel bearing right						
36	Wheel bearing left						
37	Wheel bracket						
38	Vent seal		32307		16		
39	Spring						
40	Vent button						

		Spare part number	Spare part number	Spare part number	Colours available
41	Handle				
42	Screw				
43	Handle cover				