

Spare parts Combi 4 (03/2007-04/2013)

Item no.	Article no.	Description	Quantity	Unit
10	34020-00936	Combi (E) cover kit	1	PC
20	34020-65000	Combi (E) circulation air cover, right	1	PC
40	34020-00933	Combi (E) seal kit	1	PC
50	34020-00234	Combi (E) ignitor kit	1	PC
60	34020-00235	Combi (E) combustion air motor kit	1	PC
70	34020-60400	Cover combustion air	1	PC
80	34020-00932	Combi (E) burner kit	1	PC
90	34020-60800	Combi ignition electrode kit	1	PC
100	34020-60900	Combi flame tube	1	PC
110	34020-00605	Combi heat exchanger kit	1	PC
120	34020-01500	Spiral casing VBL	1	PC
130	34020-10700	Acoustic plate 1	1	PC
140	34020-10800	Acoustic plate 2	1	PC
170	34000-04700	Fan wheel	1	PC
180	34020-61300	D.C. Motor	1	PC
190	34020-00612	Combi (E) water container kit	1	PC
200	34020-61400	Interior air hood	1	PC
210	34020-00241	Combi (E) thermostat plate kit LTF	1	PC
220	34020-61600	Warm air distributor cpl.	1	PC
230	34020-53100	Clip interior air hood	1	PC
240	34020-24000	Clips 4 pcs.	1	PC
250	34020-95900	Combi outer casing, black	1	PC

Spare parts Combi 4 (03/2007-04/2013)

Item no.	Article no.	Description	Quantity	Unit
260	34020-61700	Combi electronics housing	1	PC
270	34020-61800	Combi electronics cover	1	PC
280	34020-00687	Combi connector cover	1	PC
290	34030-18200	Combi 4 / 4 E electronics	1	PC
310	34020-00073	Combi fine wire fuse kit 10 AT, 10 pcs.	1	PC
350	34020-00240	Combi 4 (E) cable harness kit	1	PC
360	34020-57000	Earth cable flint Ignitor cpl.	1	PC
370	34020-62800	Holder thermostat plate	1	PC
380	34020-63500	Combi 4 (E) thermostat plate	1	PC
390	34020-00231	Combi (E) 2S solenoid valve kit	1	PC
410	70000-54600	U-sheet kit, 2 pcs.	1	PC
450	34020-03500	Heat conducting plate	1	PC
460	34020-63200	Water temp. sensor cable harness cpl.	1	PC